

DEPARTMENT OF TRANSPORTATION
DIVISION OF ENGINEERING SERVICES
Transportation Laboratory
5900 Folsom Blvd.
Sacramento, California 95819-4612



METHOD OF TEST FOR OPERATION OF BRIDGE PROFILOGRAPH AND EVALUATION OF PROFILES_revision_1

A. SCOPE

This test method describes the procedures for:

1. The operation of the Bridge Profilograph.
2. The procedure for determining the “counts per 100 ft” from the profilograms.
3. The procedure for locating individual high points in excess of a specified limit.

B. EQUIPMENT

1. Bridge Profilograph –
 - a. Mechanical: consists of a 12 ft long frame supported on one wheel at each end with an outrigger wheel for balancing support (see Figure 1a). The profile is recorded from the vertical movement of a wheel attached at the midpoint of the frame and is in reference to the mean elevation of the end wheels in contact with the deck surface.
 - b. Electronic: consists of a 12 ft long frame supported on 4 wheels at each end (See Figure 1b). The profile is recorded from the vertical movement of a wheel attached at the midpoint of the frame and is in reference to the mean elevation of the wheels in contact with the deck surface.
2. Profilogram –
 - a. Mechanical Profilograph: is recorded on a scale of 1 in. = 15 ft longitudinally and 1 in. = 1 in. vertically.
 - b. Electronic Profilograph: is recorded on a scale of 1 in. = 15 ft longitudinally and 1 in. = 1 in. vertically.
3. Motive Power –
 - a. Mechanical Profilograph is supplied manually from the push handle in the rear. Steering is accomplished by rotating the handle grip to move the front wheel.
 - b. Electronic Profilograph is supplied manually from the steering wheel located in the middle. The Electronic Bridge Profilograph system is a total of six pieces: the 12 ft frame section with measurement wheel, front and rear bogey wheel assemblies, steering wheel assembly, pelican housing, and computer system. A 600 count distance encoder is attached to the measurement wheel axle and a 4096 count height encoder is mounted to the measurement wheel's lever arm axle.




FIGURE 1a. Mechanical Bridge Profilograph




FIGURE 1b. Electronic Bridge Profilograph

PART 1: OPERATION OF THE BRIDGE PROFILOGRAPH OPERATION

1.A. OPERATION

When operating the profilograph, move at a speed no greater than a walk. Moving too fast will result in a profilogram that is difficult to evaluate. Sweep the deck surface clean of any loose material along the paths to be profiled. Keep the mechanical bridge profilograph's wheels clean and free of particles, which may become embedded in the tires. The measurement wheel for the electronic bridge profilograph should be checked for trueness (roundness). Obtain profiles in accordance with the specifications for the project.

1. The Mechanical Bridge Profilograph is transported in 2 pieces that readily bolt together. Mount the recorder using 2 spring clips on each end. Connect the cable from the profile wheel to the recorder for the vertical scale movement. Connect the speedometer cable hookup to the recorder for the horizontal scale movement.
2. The Electronic Bridge Profilograph is transported in 5 pieces that clamp together. Connect the height and distance cable to the electronics housing.

1.B. CALIBRATION

Check the profilograph's calibration periodically.

Mechanical and Electronic:

1. The horizontal scale can be checked by running a known distance and scaling the result on the profilogram. If the horizontal scale is in error of more than $\pm 2\%$ (0.02 in.), the rear wheel of the profilograph should be replaced with one of proper diameter and other causes should be investigated and corrected if found.
2. The vertical scale is checked by putting a gage or sturdy material of known thickness under the profile wheel and scaling the result on the profilogram. If the vertical scale is in error of more than $\pm 2\%$ (0.02 in.), the cause of the incorrect height should be investigated and corrected if found.

Electronic:

To perform the height calibration using the machined calibration blocks and base plate:

1. Place the measurement wheel on the base plate.
2. Place the measurement wheel on the 1 in. block.
3. Place the measurement wheel on the 2 in. block.
4. Remove the 2 in. block and replace with the 1 in. block for confirmation.
5. Remove the 1 in. block and set the measurement wheel on the base plate for confirmation.

The distance calibration should be performed over 0.1 mile (straight-line distance), with a tolerance of ± 1 ft.

PART 2: DETERMINATIONS OF COUNTS PER 100 FEET FROM PROFILOGRAMS

2.A. PROCEDURE

Mechanical:

1. To determine the "counts per 100 ft," use a plastic scale 1.70 in. wide and 6.66 in. long to represent a bridge deck length of 100 ft at a scale of 1 in. = 15 ft.
2. Near the center of the scale is an opaque blanking band 0.15 in. wide extending the entire length of 6.66 in. On either side of this band are scribed lines 0.10 in. apart, parallel to the opaque band. These lines serve as a convenient scale to measure deviations of the profile line above or below the blanking band. These deviations are called "scallops."
3. Electronic Bridge Profilograph: To determine the "counts per 100 ft," use a plastic scale 1.70 in. wide and 6.66 in. long to represent a bridge deck length of 100 ft at a scale of 1 in. = 25 ft.
4. Near the center of the scale is an opaque blanking band 0.15 in. wide extending the entire length of 6.66 in. On either side of this band are scribed lines 0.10 in. apart, parallel to the opaque band. These lines serve as a convenient scale to measure deviations of the profile line above or below the blanking band. These deviations are called "scallops."

2.B. METHOD OF COUNTING

1. Place the plastic scale over the profile in such a way as to "blank out" as much of the profile as possible. When this is done, any scallops that appear above and below the blanking band will be approximately balanced (See Figure 2).
2. Starting at the right end of the scale, measure and total the height of all the scallops appearing both above and below the blanking band, measuring each scallop to the nearest 0.05 in. (half a tenth of an inch). Write this total on the profile sheet near the left end of the scale together with a small mark to align the scale when moving to the next section. Short portions of the profile line may be visible outside the blanking band, but unless they project 0.03 in. or more and extend longitudinally for 0.15 in. or more on the profilogram, they are not included in the count (see Figure 2 for illustration of these special conditions).
3. When scallops occurring in the first 100 ft are totaled, slide the scale to the left, aligning the right end of the scale with the small mark previously made and proceed with the counting in the same manner. The last section counted may or may not be an even 100 ft. If not, the last section should be scaled to determine its length and then that portion of 100 ft should be prorated to equivalent 100 ft. For example:

Section Length	Counts (tenths of an inch per 100 ft)
----------------	--

100 ft	4
100 ft	3
100 ft	2
60 ft	3.33*

* Calculation for equivalent count:

Example: 2.0 counts in 60 ft prorated to 100 ft

$$\frac{2.0}{60} = \frac{C}{100} \quad \text{where: } C = \text{prorated count}$$

$$\text{Therefore } C = \frac{2.0 \times 100}{60} = 3.33$$

Electronic Profilograph

The software's parameters should have the following:

PRI ride value calculation.

Segment length of 100 ft
Blanking bank of 0.15"
2.0 ft Butterworth Filter
Filter Gain: 1.0

Scallop Settings:

Minimum Height: 0.03 in.
Minimum Width: 2.25 ft.
Resolution: 0.05 in.

Localized Roughness Settings

Bump length: 20 ft
Bump height: 0.25 in.

2.C. LIMITATIONS OF COUNT IN 100 FT SECTIONS

When the specifications limit the profile count in "any 100 ft section," the scale is moved along the profile and counts made at various locations to find those sections, if any, that do not conform to specifications. The limits are then noted on the profile and can be later located on the deck surface prior to grinding.

2.D. LIMITS OF COUNTS

Profiles of the first and last 6 ft of the section being tested cannot be obtained until the adjoining pavement or bridge section is in place. At such time that the concrete bridge approach pavement is to be evaluated, profiles should be obtained starting at least 60 ft prior to each structure or approach slab and continuing to at least 25 ft onto the bridge deck.

PART 3. DETERMINATION OF HIGH POINTS

3.A. EQUIPMENT

Use a plastic template having a line 1.33 in. long scribed on one face with a small hole or scribed mark at either end, and a slot a specified distance from and parallel to the scribed line (See Figure 3). The 1.33 in. line corresponds to a horizontal distance of 20 ft on the horizontal scale of the profilogram.

3.B. LOCATING POINTS IN EXCESS OF THE SPECIFIED LIMIT

1. At each prominent peak or high point on the profile trace, place the template so that the small holes or scribe marks at each end of the scribed line intersect the profile trace to form a chord across the base of the peak or indicated bump. The line on the template need not be horizontal. With a sharp pencil, draw a line using the narrow slot in the template as a guide. Any portion of the trace extending above this line will indicate the approximate length and height of the deviation in excess of the specified limit.
2. There may be instances where the distance between easily recognizable low points is less than 20 ft. In such cases, a shorter chord length must be used in making the scribed line on the template tangent to the trace at the low points. It is the intent, however, of this requirement that the baseline for measuring the height of bumps will be as nearly 20 ft as possible, but in no case exceed this value.
3. When the distance between prominent low points is greater than 20 ft, make the ends of the scribed line intersect the profile trace when the template is in a nearly horizontal position. A few examples of the procedure are shown in Figure 3.


C. HEALTH AND SAFETY

It is the responsibility of the user of this test method to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use. Prior to handling, testing or disposing of any materials, testers must be knowledgeable about safe laboratory practices, hazards and exposure, chemical procurement and storage, and personal protective apparel and equipment.

Caltrans Laboratory Safety Manual is available at:


http://www.dot.ca.gov/hq/esc/ctms/pdf/lab_safety_manual.pdf

End of Text
(California Test 547 contains 8 pages)




TYPICAL CONDITIONS

Scallops are areas enclosed by profile line and blanking band



Small projections which are not included in the count



SPECIAL CONDITIONS

Rock or dirt on deck (not counted)



Double peaked scallop (only highest part counted)





FIGURE 2. Method for Obtaining Profile Counts



Plastic Bump Template




FIGURE 3. Method for Placing Template When Locating Bumps to Be Reduced