

Bridge Design Details 7.14 August 2025

Bent Cap Pipe Pin Details




Figure 7.14.1 Pipe Pin Details

Notes:

1. Outer Pipe to seat tightly against $\frac{1}{4}$ " thick rubber gasket placed on concrete around pipe pin.
2. Adjust spacing of main bent cap, column vertical, and column hoop reinforcement to allow placement of pipe pin, as approved by Engineer.
3. Pipe pin details not to be used where uplift capacity is required.