

CALTRANS BRIDGE DESIGN TEMPLATE REQUIREMENTS PACKAGE

Layout Points	Description of Layout Points
	<p>Points at the top of wall (along RW LOL) - Include a point at each change in design height.</p>
	<p>Points located at the bottom of footing (red) and top of footing (blue) A Point at the beginning of each footing step and end of each footing step</p>
<p>Example - discontinuous Points in Retaining Wall Alignment</p>	<p>Points at the top of wall (along RW LOL) - Include a point at a discontinuous Point(s) in the wall alignment or profile</p>

CALTRANS BRIDGE DESIGN TEMPLATE REQUIREMENTS PACKAGE

Layout Points	Description of Layout Points
	<p>Point located at the Centerline of each pile and the top of each pile</p>