CHAPTER 3G. DELINEATORS

Section 3G.01 General

Support:

- Delineators are particularly beneficial at locations where the alignment might be confusing or unexpected, such as at lane-reduction transitions and curves. Delineators are effective guidance devices at night and during adverse weather. An important advantage of delineators in certain locations is that they remain visible when the roadway is wet or covered by snow.
- Delineators are considered guidance devices to help road users navigate the roadway alignment, rather than warning devices.

Option:

Delineators may be used on long continuous sections of highway or through short stretches where there are changes in horizontal alignment.

Section 3G.02 <u>Design</u>

Standard:

- Delineators shall consist of retroreflective devices that are capable of clearly retroreflecting light under normal atmospheric conditions from a distance of 1,000 feet when illuminated by the high beams of standard automobile lights. They shall be mounted on crashworthy (see definition in Section 1C.02) supports.
- Retroreflective elements for delineators shall have a minimum vertical and horizontal dimension of 3 inches, or a minimum diameter dimension of 3 inches when circular.

 Support:
- Within a series of delineators along a roadway, delineators for a given direction of travel at a specific location are referred to as single delineators if they have one retroreflective element for that direction, double delineators if they have two identical retroreflective elements for that direction mounted together, or vertically-elongated delineators if they have a single retroreflective element with an elongated vertical dimension to approximate the vertical dimension of two separate single delineators.

Option:

- A vertically-elongated delineator of appropriate size may be used in place of a double delineator. Support:
- There are two classes of delineator posts and several types of retroreflectorization as shown in Figure 3G-101(CA).

Section 3G.03 Application

Standard:

- The color of delineators shall comply with the color of edge lines stipulated in Sections 3A.03 and 3B.09.
- A series of single delineators shall be provided on the right-hand side of freeways and expressways and on at least one side of interchange ramps, except when either Condition A or Condition B is met, as follows:
 - A. On tangent sections of freeways and expressways when both of the following conditions are met:
 - 1. Raised pavement markers are used continuously on lane lines throughout all curves and on all tangents to supplement pavement markings, and
 - 2. Roadside delineators are used to lead into all curves, or
 - B. On sections of roadways where continuous lighting is in operation between interchanges.

Option:

- Delineators may be provided on other classes of roads.
- A series of single delineators may be provided on the left-hand side of roadways.
- Chevron Alignment (W1-8) signs may be used instead of or in addition to standard delineators, as provided in Section 2C.08.

Standard:

06 Delineators on the left-hand side of a two-way roadway shall be white (see Figure 3G-1).

Guidance:

- A series of single delineators should be provided on the outside of curves on interchange ramps.
- Where median crossovers are provided for official or emergency use on divided highways and where these crossovers are to be marked with pavement markings, a double yellow delineator should be placed on the left-hand side of the through roadway on the far side of the crossover for each roadway.
- 09 Double or vertically-elongated delineators should be installed at approximately 100-foot intervals along acceleration and deceleration lanes.
- 10 A series of delineators should be used wherever guardrail or other longitudinal barriers are present along a roadway or ramp.

Option:

- Red delineators may be used on the reverse side of any delineator where it would be viewed by a road user traveling in the wrong direction on that particular ramp or roadway.

 Support:
- In California, except at truck escape ramps, red markers are used for wrong-way traffic. Red delineators are used at truck escape ramps.

Guidance:

- Except as provided in Paragraph 13 of Section 3B.12, delineators of the appropriate color should be used to indicate a lane-reduction transition where either an outside or inside lane merges into an adjacent lane.
- When used for lane-reduction transitions, the delineators should be installed adjacent to the lane or lanes reduced for the full length of the transition and should be so placed and spaced to show the reduction (see Section 3B.12 and Figure 3B-14 (CA)).
- On a highway with continuous delineation on either or both sides, delineators should be carried through transitions. **Standard:**
- When used on a truck escape ramp, delineators shall be red.

Guidance:

- *Red delineators should be placed on both sides of truck escape ramps.*Option:
- Where delineation is required within a paved area, surface mounted channelizers may be used. See Section 3I.01. Support:
- Examples of the use of delineators are shown in Figure 3G-101(CA). Color exceptions are shown in Figure 3G-103(CA) and 3G-104(CA).
- 19 Following are typical delineators and their uses:
 - A. Type E White Retroreflector (2 Sided). For use on the left or right of 2-lane 2-way streets and highways when it is desirable to have a reflector on the front and one on the back of the delineator facing the opposite direction of traffic.
 - B. Type F White Retroreflector (1 Sided). For use on the right of freeways and expressways. They may also be used on 2-lane 2-way streets and highways when the Type E is not needed.
 - C. Type G Yellow Retroreflector (1 Sided). For use on the left of divided highways and 2-lane highway intersections as shown in Figure 3G-102(CA).
 - D. Type J Red Retroreflector (1 Sided). For placement on both sides of Truck Escape Ramps as shown in Figure 3G-103(CA).
- As shown in Figure 3G-102(CA) and Figure 3G-104(CA), Type K(CA), Type P (CA), and Type R(CA) Object Markers are used along with delineators. See Figure 2C-17(CA) for object marker details.
- Bikeway separator posts are a type of delineator used as vertical elements to define Class IV bikeways. Refer to FHWA "Separated Bike Lane Planning and Design Guide" for information on design of bikeway separator posts. See Section 9E.102(CA) Class IV Bikeways for more details.

Section 3G.04 Placement and Spacing

Guidance:

Except as provided in Paragraph 2 of this Section, delineators should be mounted at a height, measured vertically from the bottom of the lowest retroreflective device to the elevation of the near edge of the roadway, of approximately 4 feet.

Option:

- When mounted on the face of or on top of guardrails or other longitudinal barriers, delineators may be mounted at a lower elevation than the normal delineator height recommended in Paragraph 1 of this Section.

 Guidance:
- Delineators should be placed 2 to $\frac{8}{6}$ feet outside the outer edge of the shoulder, or if appropriate, in line with the roadside barrier that is 8 feet or less outside the outer edge of the shoulder.
- Delineators should be placed at a constant distance from the edge of the roadway, except that where an obstruction intrudes into the space between the pavement edge and the extension of the line of the delineators, the delineators should be transitioned to be in line with or inside the innermost edge of the obstruction. If the obstruction is a guardrail or other longitudinal barrier, the delineators should be transitioned to be just behind, directly above (in line with), or on the innermost edge of the guardrail or longitudinal barrier.
- Delineators should not present a vertical or horizontal clearance obstacle for pedestrians.
- Delineators should be spaced 200 to 530 feet apart on mainline tangent sections. Delineators should be spaced 100 to 200 feet apart on ramp tangent sections.

 Option:
- On a highway with continuous delineation on either or both sides, the spacing between a series of delineators may be closer.
- When uniform spacing is interrupted by such features as driveways and intersections, delineators which would ordinarily be located within the features may be relocated in either direction for a distance not exceeding ¼ of the uniform spacing. Delineators still falling within such features may be eliminated.
- Delineators may be transitioned in advance of a lane transition or obstruction as a guide for oncoming traffic. Guidance:
- The spacing of delineators should be adjusted on approaches to and throughout horizontal curves so that several delineators are always simultaneously visible to the road user. The approximate spacing shown in Table 3G-1 should be used.
- The spacing between red delineators that are placed on both sides of a truck escape ramp should not exceed 50 feet for a distance that is sufficient to identify the ramp entrance. The spacing between red delineators that are placed beyond the ramp entrance should be such that adequate guidance is provided based on the length and design of the escape ramp.

Option:

When needed for special conditions, delineators of the appropriate color may be mounted in a closely-spaced manner on the face of or on top of guardrails or other longitudinal barriers to form a continuous or nearly-continuous "ribbon" of delineation.

Support:

- Examples of delineator installations are shown in Figure 3G-1. *Guidance:*
- 14 If used on the State Highway System, delineators should be placed as follows:
 - A. On the outsides of highway curves of 3000 feet radius or less (including medians in divided highways), freeway exit and entrance ramps and connectors. Exception to this is where a median barrier is delineated as shown in the Median Barrier Delineation Detail in Figure 3G-105(CA). Delineator spacing on curves is shown in Figure 3G-1 and Table 3G-1.
 - B. On the right of tangent sections of freeway entrance and exit ramps, collector roads, freeway connectors and lane reduction transition sections at 200 feet spacing.
 - C. On embankments higher than 10 feet and with side slopes steeper than 4:1. The spacing of tangent sections is approximately 525 feet. For spacing on curves, see Figure 3G-1 and Table 3G-1.
 - D. On approaches to narrow bridges as shown in Figure 3G-104(CA).
 - E. On tangent sections of rural State highways where there are no reflective pavement markers, such as in snow areas. Delineator spacing is approximately 525 feet.
 - F. On all new guardrail or bridge rail installations, or when maintenance is required on existing guardrail or bridge rail, within 12 feet of the edge of traveled way and curves of 3000 feet radius or less. The spacing on tangent sections is approximately 525 feet. For spacing on curves, see Figure 3G-1 and Table 3G-1.

Option:

- Delineators may also be placed as follows:
 - A. At intersections, road approaches, and median openings, as shown in Figure 3G-102(CA).
 - B. On sections of highway with non-standard shoulder width.
- If the exit gore at an interchange is not illuminated or is partially illuminated, delineators may be placed as shown in Figure 3G-102(CA) per the following details:
 - A. Type F White Retroreflectors (1 Sided) on the right side, beginning at a distance > 5S from the theoretical gore point at 100 feet spacing.
 - B. Type G Yellow Retroreflectors (1 Sided) on the left side of the exit at 10 feet spacing and then shifting to 100 feet spacing.
 - C. Type F White Retroreflectors (1 Sided) on the right side of the mainline, downstream of the exit at 10 feet spacing.

Support:

17 Refer to Table 3G-1 for formula to calculate value of S.

Section 3G.101(CA) Culvert Markers

Support:

- Culvert markers are placed as a convenience to maintenance crews in marking locations of culvert openings. Such marking is sometimes necessary to protect culvert ends from damage from adjacent operations as well as to serve as an aid in locating culverts during storm conditions.
- Refer to Caltrans' Maintenance Manual, Chapter M1 (Pavement Delineation) for more information on culvert markers. See Section 1A.05 for information regarding this publication.

Option:

Culvert markers may be placed on both sides of the highway at those culverts where they are necessary. *Guidance:*

Culvert markers should be so placed as not to interfere with a line of delineators.

Standard:

05 Culvert markers shall not be retroreflective, or contain kilometer post marker information.

Section 3G.102(CA) Emergency Passageway Marker

Support:

Except for emergency passageways in median barriers, median openings are not allowed on freeways. *Guidance:*

- Where freeway median passageways are provided for emergency vehicles, delineation for the crossover should be as follows:
 - A. At a point, 1/5 mile in advance of the crossover, one Class 1 Delineator, with a yellow post and two 3 x 12 inch white retroreflectors stacked vertically (24 inch of white retroreflectance), should be placed on the left side of the through roadway facing approaching traffic.
 - B. At a point, 1/10 mile in advance of the crossover, one Class 1 Delineator, with a yellow post and two 3 x 12 inch yellow retroreflectors stacked vertically, should be placed on the left side as in A.
 - C. At the far side of the crossover, one Class 1 Delineator, with a yellow post and one 3 x 12 inch white retroreflector over one 3 x 12 inch yellow retroreflector stacked vertically, should be placed on the left side as in A.

Section 3G.103(CA) Narrow Bridge Signing and Marking

Support:

The placement of warning signs, object markers, delineators, and edge lines at narrow bridges is dependent upon the width of the bridge and approach roadway.

Standard:

02 Narrow bridge signing and marking shall conform to the details shown in Figure 3G-104(CA).

Section 3G.104(CA) Median Barrier Delineation

Guidance:

Median barriers should be delineated when the clearance between the barrier and the edge of traveled way is less than 8 feet.

- In general, when delineated, it should be with an approved median barrier marker, the same color as the left edge line. They should be placed on top of the barrier at 48 foot centers.
- Markers placed on the sides of barriers, near the splash zone, should be avoided because of the tendency to collect dirt which reduces their effectiveness. See Figure 3G-105(CA).