

Middle Mile Broadband Network (MMBN) Infrastructure Projects – Linear Construction Activity Notification (LCAN)

MMBN – 0450 (Rev. 10/2025)

In addition to the attached Encroachment Permit General Provisions (TR-0045), the following special provisions are also applicable to Middle Mile Broadband Network (MMBN) projects:

1. GENERAL: The California Department of Technology (CDT) is partnering with joint builders, including private broadband providers, to install broadband infrastructure within the State highway right-of-way as part of the MMBN infrastructure. "Joint Builder" refers to MMBN partners, whether the infrastructure is owned or leased by CDT.

2. APPLICABILITY: These provisions apply to CDT MMBN joint build projects when permittee elects to work under the Caltrans MMBN Programmatic Permit under the 2022 Construction General Permit (CGP).

The Caltrans MMBN Programmatic Permit is available for joint build projects located within Caltrans right-of-way. It only applies where the CGP has jurisdiction, this does not include projects located within the Lake Tahoe Hydrologic Unit or on Federal Tribal Lands.

Caltrans is the Legally Responsible Party (LRP) for the Caltrans MMBN Programmatic Permit which works under WDID number SWBPP00002 and a Caltrans' prepared Common SWPPP. Each individual joint build project would be responsible for preparing a site-specific LCAN for Caltrans review and approval. Caltrans would then submit the approved LCAN to the State Water Resources Control Board to obtain an LCAN ID number, providing the project with CGP coverage and allowing the project to begin construction.

MMBN partners also have the option to obtain CGP coverage themselves as the LRP, see Encroachment Permit Manual Attachment L for additional information. If a joint build project is located both inside and outside Caltrans right-of-way, the project may be broken into two parts for CGP coverage, as follows:

1. The Caltrans MMBN Programmatic Permit may be utilized to obtain coverage under the CGP for the portion of the project located within Caltrans right-of-way.
2. The MMBN partner must obtain their own CGP coverage as an LRP for the portion of the project located outside Caltrans right-of-way.

3.01A SUMMARY

This provision includes specifications for preparing a linear construction activity notification (LCAN) for projects under the Caltrans MMBN Programmatic Permit. An LCAN includes developing the LCAN, implementing the LCAN and Common SWPPP, providing a WPC manager, conducting WPC training, and monitoring, inspecting and correcting WPC practices. Permittee establishes an environmental risk level for each project, referred to as the LUP type.

3.01B DEFINITIONS

Common SWPPP: The SWPPP submitted with Caltrans Middle Mile Broadband Network's programmatic permit notice of intent to obtain Construction General Permit coverage. Addresses construction activities and pollutant sources associated with the Middle Mile Broadband Network projects. Provides an LCAN template as an attachment, which includes the application form and Site-Specific Plan template.

LCAN: Linear construction activity notification; provides site specific information supplementing the Common SWPPP which is prepared for each non-contiguous linear project site under the Caltrans Middle Mile Broadband Network programmatic permit before the start of construction. An LCAN includes the LCAN application and Site-Specific Plan.

Linear Underground and Overhead Project: Project to install underground and overhead linear facilities including conduits, substructures, towers, poles, cables, wires, connectors, switching, regulating and transforming equipment, vegetation management, associated ancillary facilities, underground utility mark-out, potholing, concrete and asphalt cutting and removal, trenching, excavating, boring and drilling, access road, pole and tower pad, cable and wire pull station, substructure installation, construction of tower footings and foundations, pole and tower installations, pipeline installations, welding, concrete and pavement repair or replacement, and stockpile and borrow locations.

Programmatic Permit: Caltrans Middle Mile Broadband Network's Construction General Permit coverage for multiple non-contiguous linear underground and overhead project sites with similar scope and construction activities that have the same legally responsible person and fall under a single waste discharge ID number.

Storm Event: Any weather pattern that is forecast to have a 50 percent chance

ENCROACHMENT PERMIT SPECIAL PROVISIONS

or greater probability of precipitation and a quantitative precipitation forecast of 0.5 inches or more within a 24-hour period. The event begins with the 24-hour period when 0.5 inches has been forecast and continues on subsequent 24-hour periods when 0.25 inches of precipitation or more is forecast.

3.01C SUBMITTALS**3.01C(1) General**

Submit documents marked with an X in the following table for each LUP Type: Document	LUP Type 1	LUP Type 2	LUP Type 3
LCAN	X	X	X
Construction Site Monitoring Program	--	--	--
Job site monitoring reports	X	X	X
Sampling and analysis plan	--	X	X
Sampling and analysis plan for nonvisible pollutants	X	X	X
Sampling and analysis plan for pH and turbidity	--	X	X
NAL reports	--	X	X
Receiving water monitoring trigger reports	--	--	X
Stormwater Annual Report	X	X	X
Stormwater Annual Report	X	X	X
LCTN Inspection Report	X	X	X

3.01C(2) Linear Construction Activity Notification**3.01C(2)(a) General**

Submit one printed copy and an electronic copy on a read-only CD, DVD, or other authorized data-storage device of your LCAN with your permit application. Assign a QSD to develop and revise the LCAN.

The LCAN must:

1. Refer to the Caltrans Middle Mile Broadband Network programmatic permit Waste Discharge ID number, comply with the Common SWPPP and complete the LCAN template, including:
 - 1.1. Project name and/or reference number
 - 1.2. Site Location
 - 1.3. Total site acreage and total disturbed acreage
 - 1.4. Estimated start and end date
 - 1.5. LUP type with supporting documentation

ENCROACHMENT PERMIT SPECIAL PROVISIONS

- 1.6. Contact information, including 24-hour emergency phone numbers for:
 - 1.6.1. WPC manager
 - 1.6.2. Erosion and sediment control providers or subcontractors
 - 1.6.3. Stormwater sampling providers or subcontractors
2. Describe the work involved in the installation, maintenance, repair, and removal of temporary and permanent WPC practices
3. Include maps showing:
 - 3.1. Locations of disturbed-soil areas
 - 3.2. Water bodies and conveyances
 - 3.3. Locations and types of temporary WPC practices that will be used for each Contractor-support facility
 - 3.4. Locations and types of temporary WPC practices that will be used in the work for each construction phase
 - 3.5. Locations and types of WPC practices that will be installed permanently under the Permit
 - 3.6. Water quality sampling locations
 - 3.7. Locations planned for the storage and use of potential nonvisible pollutants
 - 3.8. Receiving-water sampling locations
 - 3.9. Unique site features such as fill material, native material, hydrologic soil group type, soil erodibility, ESAs, run-on
4. List of subcontractors and material suppliers with a description of their stormwater responsibilities
5. Provide site specific drainage areas, storage and containment areas, discharge locations, list of field instruments, potential sampling locations, run-on locations, and receiving water locations as specified in the Common SWPPP's Construction Site Monitoring Program
6. Include a schedule showing when:
 - 6.1. Work activities will be performed that could cause the discharge of pollutants into stormwater
 - 6.2. WPC practices, including soil stabilization and sediment control, that will be used in the work for whichever has the longest duration in the first:
 - 6.2.1. 60 days
 - 6.2.2. Construction phase
7. Include training records for project personnel
8. Include sediment load calculations for surface water buffer when required by the Permit. Calculate sediment load of surface water buffer and

equivalent sediment load reductions achieved with WPC practices when a 50-foot undisturbed buffer cannot be maintained using RUSLE2 or other approved method.

Allow 5 business days for review.

After the State Representative authorizes the LCAN, submit one printed copy and an electronic copy on a read-only CD, DVD, or other State Representative-authorized data-storage device of the authorized LCAN.

RWQCB requires review of the authorized LCAN, the State Representative submits the authorized LCAN to the RWQCB for review and comment.

If the State Representative orders changes to the LCAN based on the RWQCB's comments, submit a revised LCAN within 3 business days.

A permit will not be issued until (1) the LCAN is authorized and (2) an LCAN ID extension is issued.

Submit a revised LCAN when:

1. Changes in work activities could affect the discharge of pollutants
2. WPC practices are added at your discretion
3. Changes in the quantity of disturbed soil are substantial
4. Objectives for reducing or eliminating pollutants in stormwater discharges have not been achieved
5. Project receives a written notice or order from the RWQCB or any other regulatory agency
6. You fail to comply with the conditions for the LUP type risk level determination
7. Changes are made to dewatering discharge WPC practices
8. Changes are made to WPC personnel or delegated functions
9. Changes are made to the project inactive status

Revise the LCAN through an amendment.

3.01C(2)(b) Construction Site Monitoring Program

3.01C(2)(b)(i) General

Review the Construction Site Monitoring Program provided in the Common SWPPP and submit site specific details as required in the LCAN template.

Revise the program as needed to reflect the current job site activities.

3.01C(2)(b)(ii) Site Inspection Reports

Submit a Stormwater Site Inspection Report as an informational submittal within

ENCROACHMENT PERMIT SPECIAL PROVISIONS

24 hours of completing an inspection. The WPC manager must oversee the preparation of this report. The report must include the location and quantity of installed WPC practices and disturbed soil.

The following site inspection reports must be performed by the QSD:

1. One within 30 days of construction activities starting
2. One within 30 days of a new site QSD
3. Once between August 1 and October 31 of each year
4. Once between January 1 and March 31 of each year
5. Within 14 calendar days after a NAL exceedance
6. Within 14 calendar days of an inactive project status
7. As requested by Water Board staff

The following site inspection reports must be performed by the QSP:

1. Once every calendar month
2. Once within 72 hours of each forecasted storm event
3. Within 14 days after a NAL exceedance
4. Before the final Linear Construction Termination Notification (LCTN) or Change of Information of all or part of the site

An assistant WPC manager cannot perform the above-mentioned QSD and QSP inspection reports.

Submit a site inspection report for the LCTN to document final site conditions with photographs and a final site map.

3.01C(2)(b)(iii) Visual Monitoring Reports

Submit a copy of the visual monitoring report on a Stormwater Site Inspection Report form for each storm event and nonstormwater discharges. The visual monitoring report must include:

1. Name of personnel performing the inspection, inspection date, and date the inspection report is completed
2. Storm and weather conditions
3. Location of any of the following:
 - 3.1. Floating and suspended material, sheen on the surface, discoloration, turbidity, odor, and source of observed pollutants for flowing and contained stormwater systems
 - 3.2. Non-stormwater discharges and their sources
4. Corrective action taken

For each storm event, the monitoring report must include:

1. Date, time, and rain gauge reading

ENCROACHMENT PERMIT SPECIAL PROVISIONS

2. Visual observations:

2.1. Within 2 business days before the predicted storm for:

- 2.1.1. Spills, leaks, or uncontrolled pollutants in drainage areas
- 2.1.2. Proper implementation of WPC practices
- 2.1.3. Leaks and adequate freeboard in storage areas

2.2. Every 24 hours during the storm event for:

- 2.2.1. Effectiveness of WPC practices
- 2.2.2. WPC practices needing maintenance and repair

2.3. Within 2 business days after a storm event for:

- 2.3.1. Stormwater discharge locations
- 2.3.2. Evaluation of design, implementation, effectiveness, and locations of WPC practices, including locations where additional WPC practices may be needed
- 2.3.3. Evidence of non-visible pollutant discharges due to a failure to implement WPC practices, a container spill or leak, or a WPC practice breach, failure, or malfunction

Keep a copy of the visual monitoring reports at the job site as part of the LCAN.

For non-stormwater discharges, the monitoring report must cover each of the following periods:

- 1. January through March
- 2. April through June
- 3. July through September
- 4. October through December

Keep a copy of the visual monitoring reports at the job site as part of the LCAN.

3.01C(2)(b)(iv) Sampling and Analysis Plan

Review the Sampling and Analysis Plan provided in the Common SWPPP and submit site specific details as required in the LCAN template.

The sampling and analysis plan must comply with the Department's *Construction Site Monitoring Program Guidance Manual*.

The sampling and analysis plan must describe:

- 1. Sampling equipment and sample containers.
- 2. Preparation of samples.
- 3. Collection and holding times.
- 4. Field measurement methods.
- 5. Analytical methods.
- 6. Quality assurance and quality control.

ENCROACHMENT PERMIT SPECIAL PROVISIONS

7. Sample preservation and labeling.
8. Collection documentation, including the names of personnel collecting samples and their training.
9. Shipment of samples.
10. Chain of custody.
11. Data management and reporting.
12. Precautions from the construction site health and safety plan, including procedures for collecting samples during precipitation. List the conditions under which you are not required to collect samples, such as:
 - 12.1. Dangerous weather
 - 12.2. Flooding or electrical storms
 - 12.3. Times outside of normal working hours
13. Procedures for collecting and analyzing 1 sample from each discharge location for each day of each storm event for a LUP Type 2 or LUP Type 3 project.
14. Procedures for collecting effluent samples at all locations where the stormwater is discharged off the job site.

The sampling and analysis plan must identify the State-certified laboratory that will perform the analyses. For a list of State-certified laboratories, go to the SWRCB's website.

Submit a revised plan if discharges or sampling locations change because of changed work activities or knowledge of site conditions.

3.01C(2)(b)(v) Sampling and Analysis Plan for Nonvisible Pollutants

Submit a sampling and analysis plan for monitoring nonvisible pollutants.

The sampling and analysis plan must identify potential nonvisible pollutants present at the job site associated with any of the following:

1. Construction materials and wastes
2. Existing contamination due to historical site usage
3. Application of soil amendments, including soil stabilization materials, with the potential to change pH or contribute toxic pollutants to stormwater

The sampling and analysis plan for nonvisible pollutants must include sampling procedures for the following conditions if observed during a stormwater visual inspection. Include a procedure for collecting at least 1 sample at each discharge location associated with one of the following nonvisible pollutant triggering conditions:

ENCROACHMENT PERMIT SPECIAL PROVISIONS

1. Materials or wastes containing potential nonvisible pollutants not stored under watertight conditions
2. Materials or wastes containing potential nonvisible pollutants stored under watertight conditions at locations where a breach, leak, malfunction, or spill occurred and was not cleaned up before the precipitation
3. Chemical applications occurring within 24 hours before precipitation or during precipitation that could discharge pollutants to surface waters or drainage systems, including applications of fertilizer, pesticide, herbicide, methyl methacrylate concrete sealant, or nonpigmented curing compound
4. Applied soil amendments, including soil stabilization materials that could change pH levels or contribute toxic pollutants to stormwater runoff and discharge pollutants to surface waters or drainage systems, unless independent test data is available to indicate acceptable concentrations of nonvisible pollutants in the material
5. Stormwater runoff from an area contaminated by the historical usage of the site that could discharge pollutants to surface waters or drainage systems

The sampling and analysis plan for nonvisible pollutants must:

1. Include sampling procedures and a schedule for:
 - 1.1. Sample collection within 8 hours from each discharge location hydraulically down-gradient from the observed nonvisible pollutant triggering condition
 - 1.2. One sample per applicable discharge location for each 24-hour period that there is a discharge, until the necessary corrective actions are completed to control further discharge of the pollutant
 - 1.3. Each nonvisible pollutant source
 - 1.4. Uncontaminated control sample
2. Identify the locations for sampling downstream and collecting control samples and the reasons for selecting those locations. Select locations for control samples where the sample does not come in contact with materials, wastes, or areas associated with potential nonvisible pollutants or disturbed soil areas.

3.01C(2)(b)(vi) Sampling and Analysis Reports**3.01C(2)(b)(vi)(A) General**

Submit an electronic copy on a read-only CD, DVD, or State Representative-

ENCROACHMENT PERMIT SPECIAL PROVISIONS

authorized data storage device, a printed copy of water quality analysis results, and the QC report within 48 hours of field sampling and within 30 days of laboratory analysis.

The QC report must include an evaluation of downstream samples and identify if levels of the tested parameter are higher than the control sample. The evaluation must include:

1. Sample ID number
2. Permit number
3. Constituent
4. Reported value
5. Analytical method
6. Method detection limit
7. Reported limit

Keep a copy of the water quality sampling and analysis results with the LCAN at the job site.

3.01C(2)(b)(vi)(B) Numeric Action Level and Numeric Effluent Limit Exceedance Reports

If a NAL or NEL is exceeded, immediately notify the State Representative. Submit a NAL exceedance report within 48 hours of the observed exceedance for pH or turbidity. Submit a NAL or NEL exceedance report within 48 hours of obtaining analytical results demonstrating a TMDL-related exceedance. The report must include:

1. Field sampling results and inspections, including:
 - 1.1. Analytical methods, reporting units, and detection limits
 - 1.2. Date, location, time of sampling, visual observations, and measurements
 - 1.3. Quantity of precipitation from the storm event
2. Description of WPC practices and corrective actions taken to manage exceedance of the NAL

3.01C(2)(b)(vi)(C) Receiving-Water Monitoring Trigger Reports

If a receiving-water monitoring trigger is exceeded, notify the State Representative and submit a monitoring trigger report within 48 hours after the conclusion of a storm event. The report must include:

1. Field sampling results and inspections, including:
 - 1.1. Analytical methods, reporting units, and detection limits

ENCROACHMENT PERMIT SPECIAL PROVISIONS

- 1.2. Date, location, time of sampling, visual observations, and measurements
- 1.3. Quantity of precipitation from the storm event
2. Description of the WPC practices and corrective actions

3.01C(3) Stormwater Annual Report

Submit 2 copies of a stormwater annual report before July 15th for the preceding construction period from July 1st through June 30th or within 15 days after construction completion if construction ends before June 30th.

The stormwater annual report must include:

1. Project information, such as a description of the project and work locations
2. Stormwater monitoring information, including:
 - 2.1. Summary and evaluation of sampling and analysis results and laboratory reports
 - 2.2. Analytical methods, reporting units, and detections limits for analytical parameters
 - 2.3. Summary of the corrective actions taken
 - 2.4. Identification of the corrective actions taken and compliance activities not implemented
 - 2.5. Summary of violations
 - 2.6. Names of the individuals performing stormwater inspections and sampling
 - 2.7. Logistical information for inspections and sampling, including location, date, time, and precipitation
 - 2.8. Visual observations and sample collection records
3. Documentation of training for individuals responsible for Permit compliance
 - 3.2. Installation, inspection, maintenance, and repair of WPC practices
 - 3.3. Development and revision of the LCAN
4. WPC Manager's signature

Allow 10 days for review. If revisions are required, the State Representative notifies you of the date the review stopped and provides comments.

Submit a revised report within 5 business days of receiving the comments. The Department's review resumes when a complete report has been resubmitted.

Submit an electronic copy on a read-only CD, DVD, or other State

Representative-authorized data storage device and 2 printed copies of the authorized stormwater annual report signed by the WPC manager.

3.01D QUALITY ASSURANCE

3.01D(1) Regulatory Requirements

Discharges of stormwater from the project must comply with NPDES General Permit for Storm Water Discharges Associated with Construction and Land Disturbance Activities (Order No. 2022-0057-DWQ, NPDES No. CAS000002) referred to herein as *Permit*.

3.01D(2) Sampling

3.01D(2)(a) General

Assign trained personnel to collect water quality samples. The personnel must comply with the equipment manufacturer's instructions for the collection of samples, analytical methods, and equipment calibration.

Samples taken for laboratory analysis must comply with water quality sampling procedures and be analyzed by a State-certified laboratory under 40 CFR part 136, *Guidelines Establishing Test Procedures for the Analysis of Pollutants*.

For a LUP Type 2 or LUP Type 3 project, take samples for pH and turbidity from representative and accessible locations upstream and downstream of each discharge point. Sample run-on from surrounding areas if there is a reason to believe run-on may contribute to an NAL or NEL exceedance.

If the receiving water monitoring trigger for turbidity is exceeded for a LUP Type 3 project, take samples and analyze the suspended sediment concentration under ASTM D3977 at a minimum detection limit of 5 mg/L.

3.01D(2)(b) Numeric Action Levels

For a LUP type 2 or LUP type 3 project, test the sample at each discharge location. For projects with dewatering activities, test each dewatering discharge location within the first hour of discharge and daily for continuous dewatering discharges. The test methods and at the detection limits for the NALs shown in the following table:

ENCROACHMENT PERMIT SPECIAL PROVISIONS

Quality characteristic	Test method	Detection limit (min)	NAL
Turbidity (max, NTU)	Field test with calibrated portable instrument	1	250
pH	Field test with calibrated portable instrument	0.2	6.5–8.5

3.01D(2)(c) Receiving-Water Monitoring Triggers

For a LUP type 3 project, test the receiving water under the test methods and at the detection limits for the monitoring triggers shown in the following table:

Quality characteristic	Test method	Detection limit (min)	Monitoring trigger
Turbidity (max, NTU)	Field test with calibrated portable instrument	1	500
pH	Field test with calibrated portable instrument	0.2	6.0–9.0

Collect a minimum of 1 upstream receiving water sample from an accessible and safe location that is representative of the receiving water, as close as possible to the discharge location, and upstream from the discharge location. Collect a minimum of 1 downstream receiving water sample from an accessible and safe location that is representative of the receiving water, as close as possible to the discharge location and downstream from the discharge location. Collect samples once every 24-hour period of the storm event at each discharge location where discharge has occurred. Analyze the sample for the parameter that triggered the receiving water monitoring, including either pH or turbidity, or both.

3.01D(3) Water Quality Control

Collect water samples:

1. During an observed nonvisible pollutant triggering condition for:
 - 1.1. Each nonvisible pollutant source at each hydraulically down-gradient discharge location
 - 1.2. A corresponding uncontaminated control sample
2. During a storm event for:
 - 2.1. Each nonvisible pollutant source and a corresponding uncontaminated control sample
 - 2.2. Turbidity, pH, and other constituents as required
 - 2.3. All discharge locations for LUP type 2 or LUP type 3 project

ENCROACHMENT PERMIT SPECIAL PROVISIONS

Collect samples for each 24-hour period of a storm event resulting in a discharge. Nonvisible pollutant sampling can end before the end of the storm event if corrective actions are completed prior to further discharge of the pollutant.

Collect samples during (1) normal working hours and (2) within 8 hours of each nonvisible pollutant triggering condition as listed in the *Sampling and Analysis Plan for Nonvisible Pollutants* section of this special provision. Samples do not need to be collected during dangerous weather conditions, such as flooding or electrical storms.

Collect receiving water samples for a LUP type 3 project and if a direct discharge to receiving waters occurs.

If a downstream sample shows an increased level of turbidity, pH, or other constituent, assess WPC practices, site conditions, and surrounding influences to determine the probable cause for the increase.

The State Representative may order laboratory analysis of stormwater samples.

3.01D(4) Training

For project managers, supervisory personnel, subcontractors and employees that are assistant WPC managers involved in WPC work:

1. Provide stormwater training for:
 - 1.1. Common SWPPP and LCAN roles and responsibilities
 - 1.2. Forecast information
 - 1.3. Documentation and reporting procedures
2. Provide site-specific training for:
 - 2.1. Visual inspections
 - 2.2. Sampling procedures
 - 2.3. Common SWPPP, LCAN and WPC implementation activities relevant to the assistant WPC manager's assigned responsibilities

3.01D(5) Responsibilities

Before assigning an assistant WPC manager, the WPC manager must ensure the assistant WPC manager has a competent understanding of the following WPC work:

1. Visual inspections
2. Sampling procedures
3. Common SWPPP, LCAN and WPC implementation tasks

The assistant WPC manager must record and report issues to the QSP within 24-

ENCROACHMENT PERMIT SPECIAL PROVISIONS

hours of a WPC corrective action. The assistant WPC manager must follow the QSP Delegate responsibilities detailed in the *Permit*.

3.02 CONSTRUCTION

Obtain, install, and maintain a rain gauge at the job site. Observe and record precipitation daily.

Manage work activities to reduce discharge of pollutants into surface waters, groundwaters, and municipal-separate storm sewer systems.

Monitor and inspect WPC practices at the job site.

Notify the State Representative within 6 hours of:

1. Identifying discharges into receiving waters or drainage systems that are causing or could cause water pollution
2. Receiving a written notice or order for the project from the RWQCB or any other regulatory agency

Continue WPC implementation during any suspension of work activities.

Submit a SWPPP, obtain your own *Permit* coverage and pay all associated costs if you do any of the following:

1. Include any work which does not meet the definition of a linear underground or overhead project
2. Include any work located outside Caltrans right-of-way
3. Violate any conditions of the Caltrans Middle Mile Network Programmatic Permit or Common SWPPP

Return disturbed areas to pre-construction or equivalent condition at the end of each working day for LUP Type 1 projects.